

Strengningsoversigt – SunPower panel og Longi Panel

Som udgangspunkt skal panelerne altid fordeles ligeligt ud på strengene.

TIL MONTØRER						
SUNPOWER 375						
					TOTAL FOR INVERTER	
Inverter	min/streng	max/streng	antal streng	min paneler	max paneler	
Sonnen Hybrid 4.6 - 2MPPT	4	16	2	4	17	
Huawei SUN2000-2KTL-L1	3	8	2	4	8	
Huawei SUN2000-3KTL-L1	3	11	2	8	12	
Huawei SUN2000-3.68KTL-L1	3	11	2	9	16	
Huawei SUN2000-5KTL-M1	6	20	2	12	22	
Huawei SUN2000-6KTL-M1	6	20	2	15	26	
Huawei SUN2000-8KTL-M1	6	20	2	19	35	
Huawei SUN2000-10KTL-M1	6	20	2	22	40	
Huawei SUN2000-12KTL-M2	6	20	4	29	52	
Huawei SUN2000-15KTL-M2	6	20	4	36	66	
Huawei SUN2000-17KTL-M2	6	20	4	40	74	
Huawei SUN2000-20KTL-M2	6	20	4	47	80	
Huawei SUN2000-33KTL-A	6	21	8	64	120	
Huawei SUN2000-36KTL	6	21	8	86	160	
Huawei SUN2000-60KTL-M0	6	21	12	141	252	
Fronius Symo 12.5-3-M	6	17	3	27	43	
Fronius Symo 15.0-3-M	6	17	5	32	52	
Fronius Symo 17.5-3-M	6	17	5	38	60	
Fronius Symo 20.0-3-M	6	17	5	43	69	
Growatt MIC 1500TL-X	2	5	1	4	5	
Growatt MIC 2500TL-X	2	8	1	6	8	
Growatt MIN 3000 TL-XE	3	10	2	7	10	
Growatt MIN 3600 TL-XE	3	11	2	8	12	
Growatt MOD 4000 TL3-X	6	13	2	9	13	
Growatt MOD 5000 TL3-X	6	17	2	11	17	
Growatt MOD 6000 TL3-X	6	20	2	13	20	
Growatt MOD 7000 TL3-X	6	21	2	15	24	
Growatt MOD 8000 TL3-X	6	21	2	18	27	
Growatt MOD 9000 TL3-X	6	21	2	20	31	
Growatt MOD 10000 TL3-X	6	21	2	22	34	
Growatt MOD 11000 TL3-X	6	21	2	24	38	
Growatt SPH 3.6 - 2MPPT	5	11	2	5	21	

RO	RV	RVV	RA	RI	RL
TIL MONTØRER					
LONGI 360					
					TOTAL FOR INVERTER
Inverter	min/streng	max/streng	antal strenger	min paneler	max paneler
Sonnen Hybrid 4.6 - 2MPPT	4	17	2	4	18
Huawei SUN2000-2KTL-L1	3	8	2	4	8
Huawei SUN2000-3KTL-L1	3	12	2	8	12
Huawei SUN2000-3.68KTL-L1	3	12	2	9	16
Huawei SUN2000-5KTL-M1	6	22	2	13	22
Huawei SUN2000-6KTL-M1	6	22	2	15	27
Huawei SUN2000-8KTL-M1	6	22	2	20	36
Huawei SUN2000-10KTL-M1	6	22	2	23	41
Huawei SUN2000-12KTL-M2	6	21	4	30	55
Huawei SUN2000-15KTL-M2	6	21	4	37	68
Huawei SUN2000-17KTL-M2	6	21	4	42	77
Huawei SUN2000-20KTL-M2	6	21	4	49	84
Huawei SUN2000-33KTL-A	6	22	8	67	125
Huawei SUN2000-36KTL	6	22	8	89	166
Huawei SUN2000-60KTL-M0	6	22	12	147	264
Fronius Symo 12.5-3-M	6	18	3	28	45
Fronius Symo 15.0-3-M	6	18	5	34	54
Fronius Symo 17.5-3-M	6	18	5	39	63
Fronius Symo 20.0-3-M	6	18	5	45	72
Growatt MIC 1500TL-X	2	5	1	4	5
Growatt MIC 2500TL-X	2	9	1	6	9
Growatt MIN 3000 TL-XE	3	10	2	7	10
Growatt MIN 3600 TL-XE	3	12	2	8	13
Growatt MOD 4000 TL3-X	6	14	2	9	14
Growatt MOD 5000 TL3-X	6	18	2	12	18
Growatt MOD 6000 TL3-X	6	21	2	14	21
Growatt MOD 7000 TL3-X	6	22	2	16	25
Growatt MOD 8000 TL3-X	6	22	2	18	28
Growatt MOD 9000 TL3-X	6	22	2	20	32
Growatt MOD 10000 TL3-X	6	22	2	23	36
Growatt MOD 11000 TL3-X	6	22	2	25	39
Growatt SPH 3.6 - 2MPPT	5	12	2	5	22